

4) Your wheel's firmware version is displayed in the upper right-hand corner of the Control Panel tabs. **Firmware: 34 is currently the latest version.**

